



DUCT MOUNTED AIRFLOW MEASUREMENT STATIONSIntegral Flow Straightener, Ideal for Turbulent Measuring Conditions



DIMENSIONS - CIRCULAR FLANGE								
Station Size "D"	Flange Thickness	Flange Size "F"	Casing Length "L"					
8" - 15"	.064"		8″					
16" - 44"	.064"	1-1/2"	8″					
45" - 72"	.188″	1-1/2"	10″					
73" and over	.188″	2″	12″					

DIMENSIONS - OVAL FLANGE (OPTIONAL)							
Station Width "W"		Flange Size	*Casing Length "L"				
Up to 44"	.064"	1-1/2"	8″				
Over 44"	.188″	1-1/2"	10″				
*All oval flow stations without flange have a							
casing length of 8".							





DIMENSIONS - RECTANGULAR FLANGE								
Station Size "H" or "W"	Flange Size "F"							
8" - 72" 73" and over	1-1/2" 2"							

The Series STRA Duct Mounted Airflow Measurement Stations utilize an airflow averaging element generating a velocity pressure signal similar to the orifice, venturi, and other primary elements. Single or multiple airflow elements are factory mounted and pre-piped in a casing designed for flanged connection to the ductwork.

Multiple elements are joined together for connection to a differential measurement device (gage, transmitter, etc.) for flow measurement and indication purposes. It has been developed with a honeycomb airflow straightening section for use in duct systems having highly turbulent conditions at the point of measurement.


BENEFITS/FEATURES

- Honeycomb airflow straightening section with 1/2 opening by 3"depth
- Low signal-to-noise ratio
- Factory mounted and pre-piped in a flanged duct section (casing)
- · Standard construction includes galvanized casing and 6063-T5 anodized aluminum
- · Standard airflow stations can be operated (in air) continuously in temperatures up to 350°F or intermittently in temperatures up to 400°F

APPLICATIONS

- · Building air intake and exhaust flow rate measurement
- · HVAC air flow measurement

Circular Models



SPECIFICATIONS

Accuracy: Within 2% of actual flow when installed in accordance with published recommendations.

K Factor: 0.97.

Velocity Range: 100 to 10,000 FPM (0.51 to 51 m/s).

Wetted Materials: Elements: 6063-T5 anodized aluminum; Casings: 16 ga G90


galvanized steel, 3003 aluminum air flow straightener.

Temperature Limits: Galvanized casings and aluminum elements 350°F (177°C) continuous operation (in air), 400°F (204°C) intermittent operation (in air).

Humidity Limits: All airflow stations 0 to 100% non condensing.

Process Connections: 1/4" compression fittings.

Rectangular or Oval Models



R - Rectangular O - Oval

IM - Internal pressure connections F - Flange for oval mount station

Note: When ordering rectangular or oval flow stations, pressure taps will always be located on the longer of the two dimensions.

*Metric dimensions available upon request



DUCT MOUNTED AIRFLOW MEASUREMENT STATIONSIntegral Flow Straightener, Ideal for Turbulent Measuring Conditions

MODEL	MODEL CHART - SERIES STRA RECTANGULAR OR OVAL														
Size	8″	10″	12″	14"	16″	18″	20″	22"	24"	26″	28"	30″	32″	34"	36″
8″	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
10″		X	Х	Х	X	Х	Х	X	X	X	Х	Х	Х	X	Х
12″			Х	Х	Х	Х	Х	X	Х	X	Х	Х	Х	Х	Х
14"				Х	Х	Х	Х	X	Х	X	Х	Х	Х	Х	Х
16″					Х	Х	Х	X	Х	X	Х	Х	Х	Х	Х
18″						Х	Х	X	Х	X	Х	Х	Х	Х	Х
20″							Х	X	Х	X	Х	Х	Х	Х	Х
22″								X	Х	X	Х	Х	Х	Х	Х
24"									Х	X	Х	Х	Х	Х	Х
26″										X	Х	Х	Х	Х	Х
28″											Х	Х	Х	Х	Х
30″												Х	Х	Х	Х
32″													Х	Х	Х
34"														Х	Х
36″															X
Note: W	Note: When ordering rectangular or oval flow stations, pressure taps will always be located on the longer of the two dimensions.								ated on th	e longer c	of the two	dimension	is.		

MODEL CHART - SERIES STRA RECTANGULAR OR OVAL 40″ 44" 66″ 72 78″ 84″ 90″ 96 102" 108" 114" 120´ Size 48 56 60 Х Х Х х Х Х Х Х Х X 10" X X X X X X X X X X X X X X X X X X 12" Х X X Χ X X Χ Χ Х X X X Х X X X 14" X X Х Χ X X X X X X X X X X 16″ X X X X Χ Χ X X Χ X X XXXXXXXXXXXXXXXXX X 18 X X X X X X X X X X X X X X X X X 20″ Х X X X X X X X X Х X X X X X X X 22" X X X X X X Х X X 24 X X X X X X X X XXXXXX 26 X 28 X X X 30″ X X X X Χ Χ X X X X X X Х X X X X Х 32 X X X X X Х X X 34" X X X X X X X Х Χ Χ х Χ Χ X X X X X X X X 36 X X X X X X X X X X 40″ X X X X X X X X X 44" X X X X Х X X X X X X X 48 X X Х Х X X X X 52" X X X X X 56 X X X X X X X X X X 60" X X X Χ X X X X 66 X X X X 72" X X Χ X X Х X X X X 78 X X X X X 84" Χ X X X 901 Х X X 96 Х X X X Χ 102" 108" X X Χ 114" X 120

MODEL	CHART -	SERIES S	STRA CIR	CULAR										
Size	8″	10″	12"	14"	16″	18″	20″	22″	24"	26″	28″	32″	36″	40″
	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
Size	44"	48″	54"	60″	66″	72″	78″	84"	90″	96″	102"	108″	114"	120″
	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х

Note: When ordering rectangular or oval flow stations, pressure taps will always be located on the longer of the two dimensions

OPTIONS						
To order add suffix:	Description					
-F	Flange (oval stations only)					
-IM	Internal pressure connections (rectangular stations only)					